Overview

The 3Com Ethernet SLD contains a component that supports the 3Com 1GB Ethernet controller chips. The component supports driver version 1.0.0.44. Only the SLD is supplied in the ZIP file. You will need the driver files to go with the component. Here is the list of files:

EL2000x.inf EL2K_CPP.dll EL2K_XP.sys

Instructions:

- 1. If the files are part of an installation application, **install** the Ethernet driver on an XP Pro system to capture the files listed above. If the files are already extracted, continue with step 2.
- 2. **Download** the ZIP file containing the SLD.
- 3. Extract the contents of ZIP file to your hard drive.
- 4. Create a new directory in the same directory as the SLD called Files.
- 5. **Copy** the extracted driver files listed above to the **Files** directory. The Repository path is relative to the SLD. The Repository has been setup so the files are one directory level below the SLD.
- 6. **Import** the SLD into the XPe data base using Component Database Manager.

For any questions, please contact us at <u>www.sjjmicro.com</u> / <u>support@sjjmicro.com</u>.