

MAGTEK MSR XML Setup Overview

USB HID MSR devices are supported by Example Service Object that comes with the POS for .NET SDK support. To setup the service object, either a control config XML file, that maps the Example Msr service to the hardware ID for the MagTek Msr, is placed in the C:\Program Files\Common Files\Microsoft Shared\Point Of Service\Control Configurations folder, or add a HardwareID attribute to the Example Msr service object and recompile.

The MAGTEK_MSR.XML file is a control config XML that you can drop into your system and the Example service object is ready for use with the MSR. The XML file is setup for the MAGTEK Msr Model 21040101. You may have to edit the file with the appropriate HID ID numbers for your MSR. You can find the HID ID with the help of Device Manager and looking for the Hardware ID for the USB device.

Note: The XML is provided as is without any warranty.

Instructions:

1. Make sure POS for .NET 1.1 is installed on the system.
2. **Download** the ZIP file containing the MAGTEK_MSR.xml file.
3. **Extract** the contents of the ZIP file to your hard drive.
4. **Copy** the Microsoft.PointofService.ExampleServiceObjects.dll to the C:\Program Files\Common Files\Microsoft Shared\Point Of Service\Control Configurations folder. This configures the SO, and a POS for .NET application can create an instance of the MSR.

For any questions, please contact us at www.sjjmicro.com / support@sjjmicro.com.